

COMPLETE CARRIER ASSEMBLY			ITEM NO.	MH PART NO.	DESCRIPTION	QTY. REQ.
CARRIER P/N	DESCRIPTION	FINAL RATIO				
R22-1001	Carrier Assembly	4.25				
R22-1002	Carrier Assembly	4.56				
R22-1003	Carrier Assembly	4.92				
R22-1004	Carrier Assembly	5.29				
R22-1005	Carrier Assembly	5.65				
R22-1010	Carrier Assembly	5.83				
R22-1000	Carrier Assembly	6.11				
R22-1006	Carrier Assembly	6.27				
R22-1007	Carrier Assembly	6.68				
R22-1008	Carrier Assembly	7.14				
R22-1009	Carrier Assembly	7.72				
ITEM NO.	MH PART NO.	DESCRIPTION	QTY. REQ.			
1	R22-1030	Differential Carrier Housing	1			
2	MT22-1077	Flanged Bolt, Special	14			
3	MT22-1212	Taper Roller Bearing	1			
4	MT22-1078	Taper Roller Bearing	1			
5	MT22-1079	Bearing Adjuster, M133x2	2			
6	MT22-1080	Adjuster Lock Plate	2			
7	MT22-1081	Lock Plate	2			
8	11500773	Hex Bolt, M8x16	6			
9	11500191	Flat Lock Washer	2			
10	R22-1011	Toothed Hub	1			
11	R22-1012	Shift Fork	1			
12	MT14-1068	Vent Valve	1			
13	R22-1014	Clevis	1			
14	11504971	Hex Bolt, M5x12	2			
15	R22-1015	Spring	1			
16	R22-1016	Push Rod	1			
17	R22-1017	Washer	AR			
18	R22-1021	Differential Lock Actuating Air Chamber Assy.	2			
		AR = As Required				