

COMPLETE CARRIER ASSEMBLY				ITEM NO.	MH PART NO.	DESCRIPTION	QTY. REQ.
CARRIER P/N	DESCRIPTION	FINAL RATIO		17	R22-1021	Differential Lock Actuating Air Chamber Assy.	2
RF22-1001	Carrier Assembly	4.25		18	11500191	Flat Lock Washer	4
RF22-1002	Carrier Assembly	4.56		19	MT14-1068	Vent Valve	1
RF22-1003	Carrier Assembly	4.92		20	MT14-1070	Taper Screw Plug	1
RF22-1004	Carrier Assembly	5.29		21	R22-1040	Differential Carrier Housing Assy.	1
RF22-1010	Carrier Assembly	5.38		22	R22-1041	Dowel Pin	2
RF22-1005	Carrier Assembly	5.65		23	R22-1042	Oil Filter	1
RF22-1013	Carrier Assembly	6.11		24	R22-1043	Spring For Oil Filter	1
RF22-1006	Carrier Assembly	6.27		25	R22-1044	Gasket	1
RF22-1007	Carrier Assembly	6.68		26	R22-1045	Magnetic Screw Plug	1
RF22-1008	Carrier Assembly	7.14		27	11500779	Hex Bolt, M10x40	1
				28	11500956	Hex Nut	1
				29	R22-1084	O-Ring	1
				30	R22-1048	Shift Fork	1
						AR = As Required	
ITEM NO.	MH PART NO.	DESCRIPTION	QTY. REQ.				
1	RF22-1039	Differential Carrier Housing	1				
2	MT22-1077	Flanged Bolt, Special	46				
3	MT22-1078	Taper Roller Bearing	1				
4	MT22-1212	Taper Roller Bearing	1				
5	MT22-1029	Bearing Adjuster	2				
6	MT22-1080	Adjuster Lock Plate	2				
7	MT22-1081	Lock Plate	2				
8	11500773	Hex Bolt, M8x16	8				
9	R22-1011	Toothed Hub	1				
10	R22-1012	Shift Fork	1				
11	R22-1049A	Shim 0.20 MM	AR				
	R22-1049B	Shim 0.25 MM	AR				
	R22-1049C	Shim 0.30 MM	AR				
	R22-1049D	Shim 0.50 MM	AR				
	R22-1049E	Shim 1.00 MM	AR				
12	R22-1014	Clevis	1				
13	11504971	Hex Bolt, M5x12	2				
14	R22-1015	Spring	2				
15	R22-1016	Push Rod	2				
16	R22-1017	Washer	AR				